



1. REQUIRED STEPS OF PREPARING PAVEMENT SURFACE TO RECEIVE CURB:
  - 1.1. ROUGHEN SURFACE BEFORE PAVEMENT TAKES FINAL SET.
  - 1.2. WIRE BRUSH, BROOM, AND WASH SURFACE TO REMOVE CURING COMPOUND, DIRT, DEBRIS, ETC.
  - 1.3. JUST BEFORE PLACING CURB, WET THE SURFACE WITH WATER AND APPLY DRY PORTLAND CEMENT IN SUFFICIENT QUANTITY TO MAKE A THICK PASTE.
2. CURB SHALL BE PLACED MONOLITHICALLY UNLESS OTHERWISE APPROVED BY THE CITY ENGINEER.

REVISIONS			
NO.	COMMENTS	BY	DATE
##	DESCRIPTION	FL	MM/DD/YYYY

DATE  
01/01/2024

ST-7

